





9500MP

9500MP (January, 1984 to Present)



9500MP

9500MP (January, 1984 to Present) (cont'd.)



Ref.	Original Part No.	Substitute Part No.	Description
1	03-0920-3		Elbow Weldment, Pivot, 6-5/8"
2	03-2158-8		Pin, Gearbox Mount
3	03-4196-6		Washer, Towable Hub, Taper Brng
4	03-4206-3		Head Weldment, Mobile Pivot
5	03-4225-3		Tongue Weldment
6	03-4240-2		Brace, Leg, Mobile Pivot, 15' 7"
7	03-4267-5		Hub, Towable Wheel, Taper Brng
8	03-4269-1		Hub Assy, Towable, Taper Brng
9	03-4529-8		Caster Assembly, Right
10	03-4530-6		Caster Assembly, Left
11	03-4531-4		Caster Assembly, Front
12	03-4606-4		Brace, Lower, Riser, 61"
13	03-4840-9		Wheel Assy, 11.2 x 24 (R)
14	03-4841-7		Wheel Assy, 11.2 x 24 (L)
15	03-6828-2		Elbow Weldment, Pivot, 5-9/16"
16	03-6837-3		Elbow Weldment, Pivot, 8"
17	03-7162-5		Riser, Mobile Pivot
18	03-7164-1		Leg, Mobile Pivot
19	03-7990-9		Ring Assy, 10 Wire, Collector
20	04-0058-0		Bracket, Auto Shutdown
21	04-4227-7		Plate, Front Caster
22	04-4466-1		Plate, Rear Caster
23	04-4468-7		Retainer, Spindle
24	04-7165-6		Bracket, Main Panel
25	04-7265-4		Brace, Upper, Riser, 16-1/2"
26	06-0649-1		Tee, Pipe, 1/4"
27	06-0804-2		Screw, 1/2-13 x 1-1/4", Hex, Gr.5
28	06-0809-1		Screw, 3/4-10 x 2", Hex, Gr. 5
29	06-0841-4		Nut, 1/4-20, Hex
30	06-0956-0		Connector, Hose, 1/4" x 1/4"
31	06-0970-1		Cone, Bearing, 25581, C64
32	06-1510-4		Washer, Lock, 1/4"
33	06-1940-3		Screw, 1/2-13 x 1", Hex, Gr. 5
34	06-2085-6		Pin, Cotter, 1/4 x 2-1/4"

Ref.	Original Part No.	Substitute Part No.	Description
35	06-2153-2		Bolt, 9/16-18 x 1-5/8", Hub, Gr. 5
36	06-2154-0		Nut, 9/16-18, Wheel Lug
37	06-2159-9		Connector, Hose, 1/4 x 1/8" MPT
38	06-2221-7		Screw, 3/8-16 x 1", Hex
39	06-2226-6		Fitting, Hyd. Lub, 1/4" Self-Tap
40	06-2368-6		Nut, 3/4-10, Hex, Jam
41	06-2416-3		Nut, 5/8-11, Lock
42	06-2417-1		Nut, 3/4-10, Lock
43	06-2418-9		Nut, 1/2-13, Lock
44	06-2420-5		Nut, 3/8-16, Lock
45	06-2627-5		Nipple, Pipe, 1/4 x Close, Galv.
46	06-3193-7		Cap, Hub, Durst, K2114
47	06-3195-2		Pin, Spring, .25" x .75", PLM
48	06-3199-4		Cup, Bearing, 25519
49	06-3200-0		Seal, Grease, Chic Rawhide#20125
50	06-3205-9		Ring, Load, 1-3/4" Shaft
51	06-3208-3		Pin, Latch, Towable Wheel
52	06-3209-1		Pin, Towable Gearbox
53	06-3337-0		Screw, 5/8-11 x 4", Hex, Gr. 5
54	06-3677-9		Fitting, Relief, 1-5 PSI, 3/8"
55	06-3849-4		Mount, Rubber, Comb. Main Panel
56	06-4715-6		Gauge, Pressure, 0-100 PSI
57	10-2985-9		Screw, 1/4-20 x 3/4", Hex, Gr. 5
58	10-9745-0		Brace, Angle, Mobile Pivot, 70-1/4"
59	11-2499-9		Bracket, Shock Mount
60	11-3531-8		Tubing, 1/4" O.D., Nylon
61	11-3569-8		Gauge, Press, Liq-Fill, 0-30 PSI
62	16-0061-1		Panel, BOSS, 480 Volt
63	16-0066-1		Panel, BOSS, 380 Volt, CE
64	16-0057-4		Panel, BASIC, 480V
65	16-0062-9		Panel, BASIC, 380 Volt, CE
66	16-0058-0		Panel, VISION, 480V
67	16-0063-1		Panel, VISION, 380V, CE
68	15-1028-0		Elbow, Weldment, Pivot, 8-5/8"